



**MADE**  
IN THE **USA**

## REM-700 ACCU-LUG®

**WARNING:** MAKE SURE FIREARM IS UNLOADED BEFORE INSTALLATION. VISUALLY INSPECT CHAMBER, MAGAZINE, AND FIRING MECHANISM TO BE CERTAIN NO AMMUNITION IS IN THE FIREARM.

If glass bedding stock with HP recoil lug: Fill recoil lug pocket flush with modeling clay (or similar substance) prior to bedding to avoid permanent locking to stock.

Refer to drawing dimensions (right) for pinning recoil lug to receiver.

